

table of contents

	<i>Page</i>
Section 1 Installation	1-1
1.1 Unpacking.....	1-1
1.2 Mounting and Cabling for 51S-1/1A/1F/1AF.....	1-1
1.2.1 Power Cable.....	1-1
1.2.2 Audio Outputs.....	1-1
1.2.3 Antenna.....	1-1
1.3 Mounting and Cabling for 51S-1B.....	1-1
1.4 Supplementary Installation Data for 51S-1/1A/1F/1AF.....	1-3
1.4.1 IF. Output.....	1-3
1.4.2 External RF Gain.....	1-3
1.4.3 Mute.....	1-3
1.4.4 Sidetone.....	1-3
1.4.5 Line Output.....	1-3
1.4.6 External VFO Connection.....	1-3
1.4.7 Rejection Tuning.....	1-4
1.5 Supplementary Installation Data for 51S-1B.....	1-4
1.5.1 IF. Output.....	1-4
1.5.2 External RF Gain Control Line.....	1-4
1.5.3 Mute.....	1-4
1.5.4 Sidetone.....	1-4
1.5.5 Line Output.....	1-4
1.5.6 External VFO Connection.....	1-4
1.5.7 Rejection Tuning.....	1-4
Section 2 Operation	2-1
2.1 General.....	2-1
2.2 Frequency Reading.....	2-1
2.3 Single-Sideband Reception.....	2-1
2.4 CW Reception.....	2-2
2.5 AM Reception.....	2-2
2.6 Calibration.....	2-3
2.7 Dial Brake	2-3
Section 3 Principles of Operation	3-1
3.1 General.....	3-1
3.2 Circuit Descriptions.....	3-1
3.2.1 RF Amplifier.....	3-1
3.2.2 First Mixer.....	3-1

table of contents (cont)

	<i>Page</i>
3.2.3 Second Mixer.....	3-2
3.2.4 Third Mixer.....	3-2
3.2.5 First IF. Amplifier.....	3-3
3.2.6 Q-Multiplier.....	3-3
3.2.7 Second IF. Amplifier.....	3-3
3.2.8 Third IF. Amplifier.....	3-3
3.2.9 Product Demodulator.....	3-3
3.2.10 SSB/CW Preamplifier.....	3-3
3.2.11 Audio Amplifiers.....	3-3
3.2.12 Low-Frequency Mixer.....	3-4
3.2.13 Oscillators.....	3-4
3.2.14 Special Circuits.....	3-4
Section 4 Service Instructions.....	4-1
4.1 Preparation for Servicing.....	4-1
4.1.1 General.....	4-1
4.1.2 Chassis Removal From Cabinet.....	4-1
4.1.3 Chassis Removal From Rack Mount.....	4-2
4.2 Receiver Signal Tracing.....	4-2
4.3 Voltage and Resistance Measurements.....	4-2
4.3.1 Vacuum Tube Measurements.....	4-2
4.3.2 Transistor Measurements.....	4-4
4.4 Alignment.....	4-4
4.4.1 100-kHz Calibrator Adjustment.....	4-4
4.4.2 RF Meter Zeroing.....	4-5
4.4.3 IF. Alignment.....	4-6
4.4.4 3- to 2-MHz Variable IF. Alignment.....	4-7
4.4.5 14.5- to 15.5-MHz Band Pass Alignment.....	4-7
4.4.6 RF Alignment.....	4-7
4.4.7 Megahertz Oscillator Alignment.....	4-8
4.4.8 17.5-MHz Oscillator Alignment.....	4-9
4.4.9 LF Oscillator Alignment.....	4-9
4.4.10 Megahertz Injection Frequency Adjustment.....	4-9
4.4.11 Receiver Gain Adjustment.....	4-10
4.4.12 RF Meter Calibration.....	4-10
4.4.13 Q-Multiplier Alignment.....	4-10
4.4.14 VFO Alignment.....	4-11
4.5 Megacycles Drive Chain Replacement.....	4-11
4.6 Turret Wafer Replacement.....	4-13
4.7 Lamp Replacement	4-14

table of contents (cont)

	<i>Page</i>
Section 5 Specifications	5-1
5.1 51S-1/1A/1F/1AF/1B Receiver	5-1
5.2 Requirements for Operation.....	5-1
5.3 Specifications.....	5-2
5.4 Tube and Semiconductor Complement.....	5-5
5.5 Available Accessories.....	5-6
5.6 Difference Data	5-6
5.7 Schematic Change Information	5-6
Section 6 Parts List.....	6-1
6.1 Introduction.....	6-1
6.2 Group Assembly Parts List	6-7
6.3 Numerical Index	6-59
6.4 Reference Designation Index	6-69
Section 7 Illustrations.....	7-1

list of illustrations

<i>Figure</i>	<i>Page</i>
1-1 External Connections to 51S-1/1A/1F/1AF	1-0
1-2 600-Ohm Line and Remote RF Gain Control Options for 51S-1/1A/1F/1AF	1-2
1-3 51S-1/1A Receiver, Outline and Mounting Dimensions	1-5
1-4 51S-1/1A Receiver, Outline and Mounting Dimensions with 351E-4 Mount (C712-24-5)	1-6
1-5 51S-1F/1AF Rack Mount and 51S-1/1A Hinged Mount, Outline and Mounting Dimensions	1-7
1-6 51S-1B Receiver, Outline and Mounting Dimensions with 350D-5 Base Shockmount.....	1-8
1-7 51S-1B Receiver, Installation Details.....	1-9
2-1 Operating Controls	2-1
3-1 RF Input Circuits, Simplified Schematic Diagram	3-2
3-2 Block Diagram	3-7
4-1 Top Chassis, Alignment and Adjustment Locations (C712-14-P).....	4-4